


## QUICK RELEASE TOGGLE CLAMP


To install on the Model 150A, remove the standard vise plus the 4 bolts from the base plate. Replace 2 of the bolts in the previously empty base plate holes. The toggle clamp will fit onto those 2 bolts in their new location.

For thicker molds, remove the 6 screws on the toggle. Then re-position the toggle rear-ward and replace the screws



The clamping pressure can be adjusted by extending or retracting the clamp swivel.

For taller molds, you can remove the mold spacer block.



The optional mold-stop can be installed on either side.

**LNS**  
TECHNOLOGIES

[WWW.TECHKITS.COM](http://WWW.TECHKITS.COM)